

STEP 5

Place Slat Base on Side Rail Support and fix C.B.S Screws at the holes as shown.

