





ASSEMBLY INSTRUCTIONS

MODEL: NV3464T(SK68)#1

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all part is complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


PART LIST		
ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 pcs
B	TABLE LEG	4 pcs

NO	HARDWARE LIST	QTY
1	FLAT WASHER 	8 pcs
2	SPRING WASHER 	8 pcs
3	JCBC M6x70mm SCREW 	8 pcs
4	ALLEN KEY M4 	1 pcs

- CAUTION:**
- 1. Do not FULLY-TIGHTEN the nut or bolt untill all nut or nut bolt is ready to assembled.
 - 2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
 - 3. Keep all hardware part out of reach of children.

- INSTRUCTION:-**
- Step 1: Place Table Top (A) face down on a clean and flat surface to prevent from being scratched.
 - Step 2: Insert Table Leg (B) into the pre-drilled holes of Corner Block of Apron Frame, then tighten with Flat Washer (1), Spring Washer(2) and Hex Combination Screw (3) with Spanner (4) provided.
 - Step 3: Repeat Step 2 for other 3 legs assembly.
 - Step 4: Revert the table for completion of table assembly.

STEP 1



COMPLETED TABLE ASSEMBLY

